

Stealth Watering System™

Gravity Tank

(FLT-GT)



Philadelphia Scientific®
industrial battery innovation

Installation:

1. The unit is shipped in one carton and is completely assembled.
2. Fill Tank with deionized water.

Install the Gravit Tank at a height of at least **5 feet** above the top of the battery. If the Gravity Tank is not 5 feet above the surface of the battery the Stealth Valve may malfunction.

NOTE

This water supply is not for use with Philadelphia Scientific Water Injector System™ or Philadelphia Scientific Watering Guns

Operation Instructions:

1. Attach the output hose on the gravity tank to the Input/ Filter Assembly on the Stealth Watering System™ on the battery. Filling will begin as soon as they are connected.
3. Once the spinner stops and all the Float Indicators are up, the battery filling is complete. *The Spinner may not come to a complete stop, especially in larger systems. The battery is filled when the Spinner slows enough to clearly see the inner blades/vanes.*
4. Disconnect the Quick-Connect to stop the flow.



INJ-198
1/2" OD Clear PVC Tubing

FLT-071
Replacement Std Female Output Connection
for Stealth Water Supplies

© 2024 Philadelphia Scientific LLC. All Rights Reserved. Philadelphia Scientific and the PS logo are registered trademarks of Philadelphia Scientific. Stealth Watering System and Water Injector System are trademarks of Philadelphia Scientific LLC. E&O.E.



Philadelphia Scientific LLC 207 Progress Drive Montgomeryville, PA 18936
P: 215.616.0390 F: 215.616.0500 www.phlsci.com

PAK818
02/2024